

Ceiling Mount - Suspended Cable

INSTALLATION INSTRUCTIONS*

*Mounting Screws/Anchors not provided. (Maximum screw size is #8, or 5/16" head diameter.)

1

Mark and drill the holes for the intended location. Install appropriate anchors for the application.

2

Insert screws through the supplied threaded supports (A) and then drill into the anchors, (or through the ceiling into the toggles).

3

Determine the height of the sign and cut the provided cables (C) to identical lengths. Secure the cables to the ceiling barrels (B) using the provided 2mm allen wrench.

4

Fasten the ceiling barrels (B) to the support anchors (A) by rotating clockwise until the barrel is flush with the ceiling.

5

Attach Clamps/Forks (D) to the suspended cables (C) using the provided 2mm allen wrench (1.5mm for HID Systems). Ensure that both lengths are identical.

6

Raise the sign into place and using the provided 2mm allen wrench (3mm for HID Systems), tighten the set screw until closed. Make certain that your sign is level.

Wood: Shows a screw with a wood anchor (A).

Concrete: Shows a screw with a concrete anchor.

Drywall: Shows a screw with a toggle anchor. **CAUTION** 10lb Pullout Strength.

Suspended Ceiling: Shows a screw with a toggle anchor.

For more product information, installation tips, and quality signage merchandise, go to