

# Ceiling Mount - Suspended Cable

## INSTALLATION INSTRUCTIONS\*

\*Mounting Screws/Anchors not provided. (Maximum screw size is #8, or 5/16" head diameter.)

**1**

Mark and drill the holes for the intended location. Install appropriate anchors for the application.

**2**

Insert screws through the supplied threaded supports (A) and then drill into the anchors, (or through the ceiling into the toggles).

**3**

Determine the height of the sign and cut the provided cables (C) to identical lengths. Secure the cables to the ceiling barrels (B) using the provided 2mm allen wrench.

**4**

Fasten the ceiling barrels (B) to the support anchors (A) by rotating clockwise until the barrel is flush with the ceiling.

**5**

Attach Clamps/Forks (D) to the suspended cables (C) using the provided 2mm allen wrench (1.5mm for HID Systems). Ensure that both lengths are identical.

**6**

Raise the sign into place and using the provided 2mm allen wrench (3mm for HID Systems), tighten the set screw until closed. Make certain that your sign is level.

Wood Concrete Drywall Drywall Suspended Ceiling

**CAUTION**  
10lb Pullout Strength

For more product information, installation tips, and quality signage merchandise, go to