

# Ceiling Mount - PGS250A

## INSTALLATION INSTRUCTIONS\*



\*Anchors and wrenches for mounting screws are not provided.

Supplied mounting screws: For small signs: 1" #6, (1/8" allen wrench not provided). For large signs: 1-1/4" #8, (5/32" allen wrench not provided)

**1**

Mark and drill the holes for the intended location. Install appropriate anchors for the application.

**2**

Use an 1/8" allen wrench (not provided) to install 1" screws, or 5/32" allen wrench (not provided) for 1-1/4" mounting screws (A).

**3**

Fasten the barrels (B) to the extended combination screw (A) by rotating clockwise until the barrel is flush with the ceiling. Ensure the set screws (C) face out.

**4**

Use a 2mm allen wrench to open the set screw (C).

**5**

Raise the sign into place and using a 2mm allen wrench tighten the set screw (C) until closed.

**6**

Make certain that your sign is level.

Wood	Concrete	Drywall	Drywall	Suspended Ceiling

**CAUTION**  
10lb Pullout Strength

For more product information, installation tips, and quality signage merchandise, go to